

Required Supplies:

- 36000.1189 Cafiza Tablets (ea)
- 36000.1188 Cafiza Tablets (cs of 12)
- Clean Paper Towels

To order cleaning supplies call Bunn® at 800-626-2866

Cleaning



Open POD holder. Move white switch to the left position.



Place one Cafiza cleaning tablet in the pod holder.



Close pod holder and lock in place.



Raise the pod holder.



Remove and empty the grounds drawer.



Press the Rinse key and allow the Tiger to cycle through 4 soap and soak cycles. (Allow approx. 8 min)



Press the rinse key – the Tiger will cycle through 2 clear water rinse cycles (6/6 total).



Open the pod drawer and move the white switch to the right.



Screen as shown above will appear when cleaning is complete.

Steam wand cleaning:

Remove steam wand tip and clean thoroughly. Set aside.

Pour 1 oz Rinza in pitcher, add 1 L cold tap water.

Submerge the steam wand to the bottom of the pitcher and steam for 2 minutes.

Remove wand from pitcher.

Purge for 1/2 minute. (Use care - wand will be hot)

Attach the steam wand tip.

Wipe steam wand with clean cloth and sanitizer solution.

Air dry